

## **<sup>32</sup>P Radioactive Probe Synthesis and Preparation**

Zongtian Tong\*

Department of Cell Biology, Center for Metabolism and Obesity Research, Johns Hopkins School of Medicine, Baltimore, USA

\*For correspondence: [tongzong@gmail.com](mailto:tongzong@gmail.com)

**[Abstract]** To probe for a specific mRNA species by Northern blot, RNA from the agarose/formaldehyde gel needs to be transferred to a nylon membrane. RNA is detected by hybridization using a labeled probe. The probe is a DNA or RNA molecule that is chemically or radioactively labeled. In this protocol synthesis and preparation of a [<sup>32</sup>P]-dCTP-labeled probe is described.

### **Materials and Reagents**

1. Amersham Megaprime DNA labeling system (GE Healthcare Life Sciences, catalog number: RPN 1606)
2. Amersham Microspin G-50 Columns (GE Healthcare Life Sciences, catalog number: 27-5330-01)
3. dCTP- $\alpha$ -<sup>32</sup>P 3000 Ci/mmol (PerkinElmer)
4. TE buffer
5. EDTA

### **Equipment**

1. Scintillation counter
2. Bench-top centrifuge
3. Heat block
4. 37 °C incubator

### **Procedure**

#### A. Labeling reaction

1. Place 25 ng of template in 28  $\mu$ l TE or water in tube. Add 5  $\mu$ l of primer solution from kit.
2. Denature by incubating at 100 °C for 5 min.
3. Spin tube briefly to bring contents of tube to bottom.

4. At room temperature, add 10  $\mu$ l of labeling buffer, 5  $\mu$ l of dCTP, and 2  $\mu$ l of enzyme.
5. Mix and incubate at 37 °C for 10 min.
6. Stop reaction by addition of 5  $\mu$ l of 0.2 M EDTA.

#### B. Probe purification

1. Prepare column by vortexing to resuspend matrix. Loosen cap  $\frac{1}{4}$  turn and insert into 1.5 ml screw cap tube.
2. Spin 1 min at 735 x g. Start timer and centrifuge simultaneously.
3. Place column in a new 1.5 ml screw cap tube and slowly apply 50  $\mu$ l of sample to center of column matrix.
4. Do not disturb the column bed. Do not let sample flow around the sides of the bed.
5. Spin column for 2 min at 735 x g.
6. Purified sample is now at the bottom of the tube.
7. Heat to 100 °C and chill on ice prior to adding to hybridization.
8. Count 1  $\mu$ l of probe in scintillation counter.

#### **Acknowledgments**

This protocol has been modified and adapted in the Espenshade Lab, Johns Hopkins School of Medicine. Funding to support different projects that have used this protocol has come from NIH – National Heart, Lung, and Blood Institute, National Institute of Allergy and Infectious Diseases, the Pancreatic Cancer Action Network, and the American Heart Association.

#### **References**

1. Stewart, E. V., Nwosu, C. C., Tong, Z., Roguev, A., Cummins, T. D., Kim, D. U., Hayles, J., Park, H. O., Hoe, K. L., Powell, D. W., Krogan, N. J. and Espenshade, P. J. (2011). [Yeast SREBP cleavage activation requires the Golgi Dsc E3 ligase complex.](#) *Mol Cell* 42(2): 160-171.